TITLE SCHEMATIC DIAGRAM
FOR 900 HP ALCO-GE SWITCHER LOCOMOTIVES WITH 1-GT-584 GENERATOR, 1 GMG 158 EXCITER AUXILIARY GENERATOR SET AND 4-GE-752 MOTORS
FIRST MADE FOR ALCO
14856-A
WESTERN MARYLAND RD. NOS. 151, 152 SO-21017
7473B21
HOW TO USE THIS DIAGRAM
THE FOLLOWING POINTS MUST BE OBSERVED IN USING THIS DIAGRAM:
1. DEVICES ARE SHOWN IN THE NORMAL (DE-ENERGIZED) POSITION.
2. REVERSER (R) IS SHOWN SET UP FOR FORWARD MOTORING OPERATION
3. EACH DEVICE HAS ITS OWN SYMBOL USED WHERE EACH COIL OR CONTACT OF THE DEVICE IS USED.
ASSOCIATED DIAGRAMS
ALCO LIGHTING AND CONTROL 590S 34220
CONN. DIAGRAM - CONT. COMP. T 598S 34230
CONN. DIAGRAM - CONT. STAND 593S 34250
WIRING DIAGRAM - 18 PT. MU RECEPT 593S 34240
17LE48B6 332B645
17LE58B3 L-8835999
17FM140B1 (SEE SECT. O) 336B381
EXPLANATION OF SYMBOLS
CONTACTS
RESISTORS
CONTACTOR AND RELAY SEQUENCE TABLE
CABLE SIZES
APPARATUS TABLE
APPARATUS TABLE (CONT.)
SECTION A
SECTION B
SECTION C
SECTION D
SECTION E
SECTION F
SECTION G
SECTION H
SECTION K
SECTION L
SECTION M
SECTION N
SECTION O
SECTION P
SECTION Q
SECTION R
SECTION S
SECTION T
SECTION U